

CameraRC Deluxe Edition 1.2.2 - Release Notes

CameraRC Deluxe Edition provides tethering support for the below listed Nikon cameras.

Nikon Cameras Supported

- D40^{1,2}
- D40X^{1,2}
- D60^{1,2}
- D80^{1,2}
- D90¹
- D200^{1,2}
- D300
- D300S
- D3
- D3X
- D3S
- D4
- D4S
- D5000¹
- D5100
- D5200
- D5300
- D5500
- D600
- D610
- D700
- D750
- D7000
- D7100
- D7200
- D800
- D800E
- D810
- D810A
- Df

¹ When installed on Windows 7 or later the Compatibility Mode must be set to Windows Vista Service Pack 2.

² These models are not supported on Mac El Capitan (OSX 10.11) and newer releases.

Enhancements

- Add "Show File in Folder" option to right click on image thumbnail and thumbnails file menu.
- When downloading an update on Mac check if Mountain Lion OS and download correct version of program.

Bugs Fixed

- AE Bracketing and ADL Bracketing were not showing all values for D4 and D4S

- Program would not run Mac Mountain Lion - released special version of program to support Mountain Lion.
- Display of Gridlines and Golden Spiral were not being redrawn or removed on the Image Viewer.
- Camera Controls were slow to respond when Live View was active on Windows.
- Improved the method of camera connection on Mac when camera is turned on after program is started and there are not large number of images on camera.
- Issue with Shot Count shooting multiple images when the shot count was changed from multiple images back to 1.
- D810/810A not showing USB Speed.

Known Issues

- Images captured that are not focused in contrast mode live view (i.e., focus indicator not green) will incorrectly display the last phase detect focus point instead of displaying no focus point. The focus points are also incorrectly shown in Nikon Software as they are incorrectly stored in the image by the camera. The degree of this error varies depending on camera model.
- If there are a large number of images (100's) on the memory card installed in the camera it can take several minutes for the program to initialize.

Program Limitations

- On Mac the camera must be connected and turned on before starting the program. Also if the camera is disconnected the program must be restarted.
- Only one camera can be connected and in use by the program on a single computer.
- Hot switching between camera models (i.e, Changing cameras while the program is running) is not allowed.
- Program cannot be installed onto a network share - can only be installed on a local disk drive.

System Requirements

- Windows Vista or later
- Mac OSX 10.7 - 10.10
- 2 Gbyte of RAM
- 50 Mbyte free disk space
- Recommended screen resolution 1024 X 768 - lower resolutions supported with scaling.